



NOTES:

1. THREE POINT BLOCKING SHALL BE USED FOR D.I. PIPE.
2. CARRIER PIPE WITHIN BORES FOR SANITARY SEWER INSTALLATION SHALL BE DUCTILE IRON (CLASS 52) AND IS TO BE USED FROM MANHOLE TO MANHOLE.
3. FOR NORMAL METHOD OF INSTALLATION SEE DETAIL CAS-3. THIS METHOD (CAS-2) MAY ONLY BE UTILIZED WITH PERMISSION OF INSPECTOR.

DATE MAY 2004 HANOVER DPU	ALTERNATE CASING DETAIL SEWER	DRWG. NO. CAS-2
------------------------------------	--	---------------------------